



Serial Mode

F1958 Serial Mode is selected by pulling VMODE to a logic HIGH. The serial interface uses a 8-bit word with only 7 bits used. The serial word is shifted in LSB (D0) first. When serial programming is used, all the parallel control input pins (1, 19 - 24) must be grounded.

Massstab	101.39%	Joel	Blatt : original
Änderung	07.09.2023	13:28	ETH QUANTUMOPTICS
Ausgabe	12.10.2023	19:08	
Datei	ATTENUATOR-3-100.T3001		